




SETTING UP YOUR SOUNDBOX C80




- 1 Detach the Pop Filter**
If installed, remove the pop filter.




- 2 Insert Microphone**
Insert the microphone into the chamber and center it. Compatible with microphones 38–63 mm in diameter.



- 3 Mount the SoundBox C80**
Attach to your shock mount. If it does not secure firmly, place the SoundBox on top of the shock mount.



- 4 Reattach the Pop Filter**
Align the pop filter with the opening and press firmly into place.



AUDIO ICON

SoundBox reduces reflections while maintaining a natural, open sound.

With Flex Pro, control plosives and adjust pop filter distance without repositioning your microphone.

If you need help with setup or compatibility, contact support.

support@audioicon.com

audioicon.com